

ROTAZIONE E ANGOLI DI TRASFERIMENTO

Rotation and cam transfer angles

Angolo rotazione <i>Angular displacement</i>	Fasi del ciclo <i>Cycle phases</i>				OT15	OT25	OT35	OT55
	Rotazione <i>Rotation</i> A	Pausa <i>Dwell</i> B	Rotazione <i>Rotation</i> C	Pausa <i>Dwell</i> D				

30	45	135	45	135				
	45	270	45	0				
	60	120	60	120				
	60	240	60	0				
	75	105	75	105				
	75	210	75	0				
	90	90	90	90				
	90	180	90	0				
	120	60	120	60				
	120	120	120	0				
	150	30	150	30				
	150	60	150	0				
	180	0	180	0				

45	60	120	60	120				
	60	240	60	0				
	75	105	75	105				
	75	210	75	0				
	90	90	90	90				
	90	180	90	0				
	120	60	120	60				
	120	120	120	0				
	150	30	150	30				
	150	60	150	0				
	180	0	180	0				

60	75	105	75	105				
	75	210	75	0				
	90	90	90	90				
	90	180	90	0				
	120	60	120	60				
	120	120	120	0				
	150	30	150	30				
	150	60	150	0				
180	0	180	0					

75	120	60	120	60				
	120	120	120	0				
	150	30	150	30				
	150	60	150	0				
	180	0	180	0				

90	120	60	120	60				
	120	120	120	0				
	150	30	150	30				
	150	60	150	0				
	180	0	180	0				

 Configurazioni standard

Standard availability